

CONNECTIONS




1	RJ-45	For network and PoE connections
2	Power (12vDC)*	Power connection: 1. 12VDC + 2. GND -
3	Audio In (Red)	Audio Input Connection 1. Line Input + 2. GND
4	Audio Out (Green)	Audio Output Connection 1. Line Output + 2. GND
5	Alarm In	Alarm Input Connection Blue: Alarm Input + Orange: Alarm Input -
6	Alarm Out	Alarm Output Connection Purple: Alarm Output + Green: Alarm Output -

*12vDC power input port should be plugged when not in use.



1	Reset Button	To restore the camera to factory defaults: 1. Disconnect power for 30 seconds. 2. Reconnect power and wait 30 seconds. 3. Press and hold reset button for 20 seconds.
2	microSD Card Slot	Supports up to 1TB microSD card for Edge storage. Do not add or remove the microSD card when the camera is powered on.

Waterproof Cable



1	Thread lock cap	4	Rubber “O” ring
2	Rubber plug	5	Camera cable
3	RJ45 enclosure		

OpenEye
The Cloud Video Platform

Liberty Lake, WA, USA
509.232.5261
openeye.net

Copyright ©2026 OpenEye.
All Rights Reserved. Information contained in this document is subject to change without prior notice. OpenEye does its best to provide accurate information but cannot be held responsible for typos or mistakes.

This quick start guide provides only basic information on the camera’s settings and operation for initial installation. Please read the user manual for optimal camera configurations.

Find the latest product documentation and software.

Scan the QR code or go to openeye.net/downloads


OpenEye
The Cloud Video Platform

QUICK START GUIDE


5MP Outdoor IP Bullet
OE-C2014B5-S

38301AB


CONTENTS




OE-C2014B5-S Bullet Camera




Waterproof Cable Connector



Self-Tapping Screws & Plastic Anchors



Mounting Template



Quick Start Guide



Security Torx Tool

INSTALLATION

1. Apply template sticker to desired camera location.
2. Drill anchor holes using included mounting template.
3. Remove mounting template.
4. Insert anchors.
5. Mount camera.
6. Connect network cable with included waterproof cable connector.
7. Adjust camera view.

DEFAULT USERNAME AND PASSWORD

NOTE: OpenEye IP cameras ship without a default password.

The admin user password can be set using the following methods:

1. OpenEye recorders running Apex 2.6 or newer will automatically set a new unique password when added in setup, if a new password has not already been set.

Set the Default Camera Password
Use the QR code or link for instructions on defining a unique camera password: https://answers.openeye.net/Install/Adding_Cameras_and_Camera_Settings/Default_Camera_Password

2. Connect to the camera directly through a Web Browser and follow the onscreen prompts.
3. Use the Network Camera Manager (NCM) Utility.

   Username: admin

ASSIGNING AN IP ADDRESS

OpenEye IP cameras are set to DHCP by default. If a DHCP server is not detected after 4 minutes, the camera will default to IP address 192.168.51.2. If you are not using a DHCP server, NCM will allow you to batch configure a static IP address.
The IP address for the camera network on your Apex recorder is 192.168.51.1.

NOTE: To change this IP address please refer to your Apex recorder manual.

Selecting multiple cameras and entering IP address 192.168.51.2 will set an IP address on all selected cameras, starting at 192.168.51.2 and increase per camera.

1. Open the Network Camera Manager application.
2. Select applicable camera(s).
3. Input starting IP address, Subnet Mask, Gateway, DNS.
4. Apply changes.
5. Wait 60 seconds before refreshing NCM.

NOTE: The NCM software manual can be found at https://answers.openeye.net/Install/Adding_Cameras_and_Camera_Settings/Network_Camera_Manager

CONNECTING TO THE IP CAMERA

To access the camera setup menu, you need to open Network Camera Manager (NCM) utility. NCM is pre-installed on all OpenEye Recorders, and is also available for download on the OpenEye website for installation on your personal computer or laptop.

1. Open Network Camera Manager.
2. Locate your camera on the Network Camera Manager list.
3. To open the web browser, select the camera and click LOAD.